

QUIETBLUE LVT UNDERLAYMENT

Floating Installation

Underlay should be stored at room temperature for at least 24 hours pre-installation.

Approved Substrates

Can be installed above dry and completely cured concrete, interior plywood, Gypcrete or poured and sealed gypsum underlay, cement backer units, oriented strand board, and existing vinyl, wood, laminate, and ceramic floors.

STEP 1:

Subfloor surface must be structurally sound, clean and dry before installation. Check for protruding nails and/or defects in the subfloor. If installing over concrete, the concrete must be dry with a maximum relative humidity of 95% as per ASTM F2170.

STEP 2:

Start in a corner and begin installation of the underlayment. Unroll underlayment parallel to the wall in the opposite direction as you plan to install the flooring planks. The vapor barrier film should be facing down, against the subfloor.

STEP 3:

Roll out next row in the same manner butting foam close to first row. Do not overlap foam pad.

STEP 4:

Seal all open seams with aggressive adhesive 2" plastic tape.

STEP 5:

Install flooring per manufacturer's instructions.