

SPECIFICATION SHEET



Tarkett

THE ULTIMATE
FLOORING EXPERIENCE

Preference® Plus Resilient Sheet Flooring

28 January 2015

PRODUCT SPECIFICATIONS

Series:	36000, 86000, 64000 and 65000
Wearlayer:	Vinyl (Low Gloss)
Nominal Wearlayer Thickness:	.010" (0.25mm)
Nominal Total Thickness:	.060" (1.5mm)
Widths:	6' and 12' (1.8m and 3.6m)
Maximum Roll Size (Sq. Yds.):	6'-94 (78 m ²) 12'-188 (157 m ²)
Weight per Sq. Yd. (Lbs.):	2.51 (1.14 kg)
ASTM F-970 Static Load Limit:	75 lbs/in ² (5.27 kg/cm ²)
ASTM F 1303:	Type I, Grade 3, Class A
HUD/FHA Minimum Property Standards:	Meets Wearlayer Thickness Requirement
ASTM E-648 Flooring Radiant Panel:	Class 1
ASTM E-662 Smoke Density:	<450
FloorScore® Certification SCS-EC10.2-2007:	Yes

INSTALLATION

Use:	Residential
Installation System:	Full Spread
Location:	Below, on and above grade concrete, approved underlayment grade plywood and approved existing floors.
Adhesive:	Tarkett 201
Trowel Notch:	1/32" deep x 1/16" wide x 1/32" apart.
Seam Method:	Double-cut wet. Adhere with Tarkett 201 Adhesive. Double-cut dry. Adhere seam area with Tarkett S860 Seam Tape.
Seam Sealer:	Tarkett DT-65 Seam Sealer.

- Maintain the work area, flooring and adhesive between 65° F and 85° F (18°C - 38°C) for 48 hours before, during and after installation. Maintain relative humidity is between 40% and 70%.
- Keep material rolled face out on a sturdy core until time of installation.
- Use only cementitious based patching and leveling compounds.
- Tarkett 201 is a wet-set adhesive. Place flooring into adhesive immediately after application.
- Roll flooring in both directions with a 75-100 lb. (34-45kg) sectional floor roller.
- Do not contaminate seam edges with adhesive.
- Protect sealed seams from all traffic for a minimum of 3 hours.
- Refer to Tarkett Resilient Flooring Installation Manual for complete and detailed installation instructions.

CARE AND MAINTENANCE

- Do not replace frequently moved furniture or allow heavy traffic for at least 24 hours.
- Never slide heavy furniture or appliances across the floor. Place sheets of plywood over floor when moving furniture and appliances into position.
- Maintain post installation temperature between 65° F and 85° F. Maintain relative humidity between 40% and 70%.
- Use non staining mats or area rugs at doorways and entranceways to collect excess water, sand, grit and debris. Clean the mats and area rugs on a regular basis.
- Use smooth, hard plastic or metal furniture rests or glides under frequently moved furniture to avoid scratches and indentations. Do not use felt pads.
- Wash floor with Tarkett SureShine® Floor Cleaner or equal neutral floor cleaner. Dilute floor cleaner accordingly.

LIMITED WARRANTY

- 6 Year Wear and Manufacturing Defects.
- 6 Year Rip, Tear, Gouge and Indent.
- 6 Year Common Household Surface Stain.
- 6 Year Moisture Stain (Concrete Only)
- 6 Year Underlayment Panel Stain
- 6 Year Traffic/Asphalt Stain
- 6 Year Shoe Scuff



Tarkett

THE ULTIMATE
FLOORING EXPERIENCE